

AgBMP Loan Program

EXAMPLE PRACTICES



Conservation Tillage

- Chisel Plows
- Disk Tillers
- Cultivators
- Planters and Seed Carts
- Rippers
- Soil Finishers
- Strip Tillage
- Ridge Tillage
- Chopper Heads



Erosion Control

- Terracing
- Buffer Strips
- Grass Waterways
- Cover Crops
- Sediment Basins



Wetland Restoration

- Wetland Restoration
- Shoreline Restoration
 - Stabilization
 - Planting



Chemical Management

- Variable Rate Technology
- GPS Control Systems
- Flow Metering
- Secondary Containment



Other Practices

- Flood Control
 - Ring Dikes
 - Culverts and Diversions
- Well Relocation and Sealing
- Conservation Drainage
 - Control Structures
 - Bioreactors
- Field Windbreaks
- Irrigation Controls
 - Metering
 - Drop Heads



Feedlot Improvements

Manure Storage Basins

- Earthen Basins
- Lined Basins
- Concrete Basins
- Slurrystores




Structural Feedlot Improvements

- Concrete Slabs
- Scrape Alleys
- Retaining Walls
- Diversions and Curbing
- Pit Aprons



Landscaping and Diversions

- Filter Strips
- Natural Buffers



Livestock Exclusion

- Cattle Fencing
- Controlled Grazing
- Roof Runoff Control
- Monoslope Feedlot Conversions
- Gutters and Runoff Control



Composting Facilities

Odor Control Practices

Manure Management

Manure Spreading Equipment

- Terragators
- Box Spreaders
- Liquid Manure Spreaders
- Drag Lines
- Fertigation Equipment



Incorporation Equipment

Tanker Trucks

Skid Steers

Manure Agitation and Pumping

Methane Digester



Septic Systems

Mound Septic Systems


At-Grade Systems

Septic Repair or Replacement

New Septic Systems

Cluster Systems

Central Sewer Connections



Any Practice that Improves Water Quality!

All projects must be approved by a local Soil & Water Conservation District or Environmental Office.

Please Visit our website for more information: www.mda.state.mn.us/agbmlpans